

Nr. Cabina	Nr. Inverter	Nr. stringhe	Lunghezza cavo (m)
C01	INV01	17	60
	INV02	17	30
	INV03	17	60
	INV04	15	40
	INV05	15	40
	INV06	16	50
	INV07	16	60
	INV08	16	80
	INV09	15	90
	INV10	15	130
	INV11	15	190
C02	INV01	14	130
	INV02	14	110
	INV03	14	90
	INV04	16	70
	INV05	15	40
	INV06	15	30
	INV07	15	60
	INV08	17	120
	INV09	16	90
	INV10	16	70
	INV11	16	40
	INV12	16	30
	INV13	16	50
	INV14	16	70
	INV15	16	90
	INV16	16	100
	INV17	16	120
INV18	16	140	
INV19	16	160	
INV20	16	170	
C03	INV01	16	110
	INV02	16	80
	INV03	16	60
	INV04	16	50
	INV05	14	40
	INV06	16	30
	INV07	16	40
	INV08	16	50
	INV09	16	70
	INV10	14	80
	INV11	14	100
	INV12	14	110
	INV13	16	140
C04	INV01	16	260
	INV02	16	230
	INV03	16	210
	INV04	16	180
	INV05	16	150
	INV06	16	110
	INV07	16	80
	INV08	16	30
C05	INV01	16	100
	INV02	16	60
	INV03	14	30
	INV04	14	50
	INV05	16	90
	INV06	14	110
	INV07	15	130
C06	INV01	15	290
	INV02	16	260
	INV03	14	240
	INV04	14	220
	INV05	14	200
	INV06	14	180
	INV07	14	160
	INV08	16	140
	INV09	16	120
	INV10	16	90
	INV11	16	80
	INV12	16	50
	INV13	16	40
	INV14	16	40
	INV15	16	70
	INV16	16	100
	INV17	16	120