



NR. CABINA → Cxx-INVyy ← NR. INVERTER

Nr. Cabina	Nr. Inverter	Nr. stringhe	Lunghezza cavo (m)
C02	INV01	14	130
	INV02	14	110
	INV03	14	90
	INV04	16	70
	INV05	15	40
	INV06	15	30
	INV07	15	60
	INV08	17	120
	INV09	16	90
	INV10	16	70
	INV11	16	40
	INV12	16	30
	INV13	16	50
	INV14	16	90
	INV15	16	100
	INV16	16	120
	INV17	16	140
	INV18	16	160
	INV19	16	170
	INV20	16	