EMERGENZA GAS
INCREMENTO DI CAPACITÀ DI RIGASSIFICAZIONE (DL 17.05.2022, n. 50)
FSRU Ravenna e Collegamento alla Rete Nazionale Gasdotti

Rapporto Preliminare di Sicurezza per la fase di Nulla Osta di Fattibilità (NOF) ai sensi del D.Lgs. 105/15

ALLEGATO D.8.1-C
Planimetrie Antincendio FSRU

Rev.	Descrizione	Elaborato	Verificato	Approvato	Data
1	Emissione per permessi	V. Romano	A. Romano	G. Romano	23/09/2022
0	Emissione per permessi	A. Visigoti	A. Romano	G. Romano	06/07/2022

Documento di proprietà **Snam**. La Società tutelerà i propri diritti in sede civile e penale a termini di legge.

FIRE CONTROL & SAFETY PLAN

FOR HN 2074 "BW SINGAPORE"

PRINCIPAL DIMENSIONS

LENGTH O.A.	333.1 M
LENGTH B.P.	321.0 M
BREADTH MOULDED	60.4 M
DEPTH MOULDED	30.5 M
DRAUGHT DESIGNED	11.0 M
DRAUGHT SUMMER LOAD	12.5 M
DRAUGHT SCANTLING	12.5 M
DEADWEIGHT CAPACITY	300,000 tonnes, plus 10 %
CALL SIGN	D5YG8
IMO NO.	9804455
SHIP NAME	BW SINGAPORE

LIST OF FIRE CONTROL & SAFETY PLAN

SYMBOL	DESCRIPTION	QTY (DECK)	QTY (SYS)
	SEE PLAN		
	PRIMARY ESCAPE ROUTE		
	SECONDARY ESCAPE ROUTE		
	A-CLASS STEEL FIRE DOOR		
	A-CLASS HINGED SELF-CLOSING FIRE DOOR		
	B-CLASS STEEL FIRE DOOR		
	B-CLASS HINGED SELF-CLOSING FIRE DOOR		
	"A" CLASS DIVISION		
	"B" CLASS DIVISION		
	EMERGENCY EXIT		

FIRE PROTECTION DIVISIONS

PROFILE



ACC. B-DECK



NAV. BRI-DECK

ACC. A-DECK



ACC. D-DECK



EL. MOTOR & CARGO MACH. RM PLAN



ACC. C-DECK



(IN PASSAGE WAY(P))

TRUNK & UPPER DECK PLAN



(IN PASSAGE WAY(S))

AFT. SUNKEN DECK



E/R 2ND DECK

S/G ROOM



E/R 3RD DECK

S/G ROOM (4TH DECK LEVEL)



E/R 4TH DECK

E/R FLOOR DECK



BOSUN STORE



MECHANICAL VENTILATION FAN LIST

SYMBOL	NO.	CAPACITY	PURPOSE	QTY	LOCATION
	1	21,912	M/E RM	1	ENGINEROOM
	2	16,260	M/E RM	1	ENGINEROOM
	3	6,028	SWITCHBD SPACE EXHAUST	1	ENGINEROOM
	4	6,028	SWITCHBD SPACE SUPPLY	1	ENGINEROOM
	5	1,180	CAN ST SUPPLY	1	ENGINEROOM
	6	450	LIFT-M/E ROOM EXHAUST	1	ENGINEROOM
	7	765	CHEMICAL EXHAUST	1	ENGINEROOM
	8	475	AUTHORITY ROOM EXHAUST	1	ENGINEROOM
	9	300	SAFETY CAN & V.C.S EXHAUST	1	ENGINEROOM
	10	370	PAINTS & BAGGAGE LOR EXH	1	ENGINEROOM
	11	300	SPRAY BOOTH & STORE EXH	1	ENGINEROOM
	12	300	STORES & LOR EXHAUST	1	ENGINEROOM
	13	1,200	CHEMICAL STORE EXHAUST	1	ENGINEROOM
	14	1,200	CHEMICAL STORE SUPPLY	1	ENGINEROOM
	15	650	PAINT STORE EXHAUST	1	ENGINEROOM
	16	270	CAL POLY-CHEM.DEP. RM EXH.	1	ENGINEROOM
	17	600	GARBAGE STORE EXHAUST	1	ENGINEROOM
	18	650	REFRIG.R WORKSHOP EXHAUST	1	ENGINEROOM
	19	16,800	BOSUN STORE SUPPLY	1	HOLD
	20	38,700	PMS PUMP RM SUPPLY	1	HOLD
	21	10,000	TWO STORES RM SUPPLY	1	HOLD
	22	10,000	TWO STORES RM EXHAUST	1	HOLD
	23	45,120	THINNER RM EXHAUST	1	HOLD
	24	27,900	ELECTRIC MOTOR RM SUPPLY	1	ENGINEROOM
	25	180,000	ENGINE ROOM SUPPLY	1	ENGINEROOM
	26	180,000	ENGINE ROOM SUPPLY	1	ENGINEROOM
	27	90,420	ENGINE ROOM SUPPLY	1	ENGINEROOM
	28	16,000	M/C PURIFIER ROOM EXHAUST	1	ENGINEROOM
	29	16,000	M/C PURIFIER ROOM SUPPLY	1	ENGINEROOM
	30	21,600	M/C BOILER ROOM EXHAUST AIR FROM ACCOMMODATION	1	ENGINEROOM
	31	2,000	CONTROL ROOM EXHAUST AIR FROM ACCOMMODATION	1	ENGINEROOM
	32	1,000	CONTROL ROOM SUPPLY AIR FROM ACCOMMODATION	1	ENGINEROOM
	33	720	ELECTRICAL EQUIPMENT ROOM EXHAUST	1	ENGINEROOM
	34	40,000	CARGO MACHINERY RM EXHAUST	1	ENGINEROOM
	35	1,665	CO2 RM EXHAUST	1	ENGINEROOM
	36	24,000	STEERING GEAR RM SUPPLY	1	ENGINEROOM

FIRE & SMOKE DAMPER LIST

SYMBOL	NO.	PURPOSE	QTY	LOCATION
	1	FIRE DAMPER FOR CSR SUPPLY AIR	1	engine room
	2	FIRE DAMPER FOR CSR RETURN TRUNK	1	engine room
	3	FIRE DAMPER FOR LIFT TRUNK SUP. AIR	1	engine room
	4	FIRE DAMPER FOR CSR RETURN TRUNK	1	engine room
	5	FIRE DAMPER FOR M/E CASING SUPPLY AIR TRUNK	1	ENGINEROOM
	6	FIRE DAMPER FOR M/E CASING RETURN TRUNK	1	ENGINEROOM
	7	FIRE DAMPER FOR E/ROOM SUPPLY AIR TRUNK	1	ENGINEROOM
	8	FIRE DAMPER FOR E/ROOM RETURN TRUNK	1	ENGINEROOM
	9	FIRE DAMPER FOR CHECK AIR RETURN TRUNK	1	ENGINEROOM
	10	FIRE DAMPER FOR CHECK AIR SUPPLY TRUNK	1	ENGINEROOM
	11	FIRE DAMPER FOR CARGO CTRL ROOM SUPPLY AIR	1	engine room
	12	FIRE DAMPER FOR CARGO CTRL ROOM RETURN AIR	1	engine room
	13	FIRE DAMPER FOR WORKSHOP SUPPLY AIR	1	engine room
	14	FIRE DAMPER FOR WORKSHOP EXHAUST AIR	1	engine room
	15	Battery Locker FIRE DAMPER FOR SUPPLY AIR	1	engine room
	16	Battery Locker FIRE DAMPER FOR EXHAUST AIR	1	engine room
	17	FIRE DAMPER FOR SUPPLY AIR TRUNK FOR ACCOMMODATION	1	engine room
	18	FIRE DAMPER FOR RETURN AIR TRUNK FOR ACCOMMODATION	1	engine room
	19	FIRE DAMPER FOR SUPPLY AIR TRUNK FOR ACCOMMODATION	1	engine room
	20	FIRE DAMPER FOR RETURN AIR TRUNK FOR ACCOMMODATION	1	engine room
	21	FIRE DAMPER FOR SUPPLY AIR TRUNK FOR ACCOMMODATION	1	engine room
	22	FIRE DAMPER FOR RETURN AIR TRUNK FOR ACCOMMODATION	1	engine room
	23	FIRE DAMPER FOR SUPPLY AIR TRUNK FOR ACCOMMODATION	1	engine room
	24	FIRE DAMPER FOR RETURN AIR TRUNK FOR ACCOMMODATION	1	engine room
	25	FIRE DAMPER FOR SUPPLY AIR TRUNK FOR ACCOMMODATION	1	engine room
	26	FIRE DAMPER FOR RETURN AIR TRUNK FOR ACCOMMODATION	1	engine room
	27	FIRE DAMPER FOR SUPPLY AIR TRUNK FOR ACCOMMODATION	1	engine room
	28	FIRE DAMPER FOR RETURN AIR TRUNK FOR ACCOMMODATION	1	engine room
	29	FIRE DAMPER FOR SUPPLY AIR TRUNK FOR ACCOMMODATION	1	engine room
	30	FIRE DAMPER FOR RETURN AIR TRUNK FOR ACCOMMODATION	1	engine room
	31	FIRE DAMPER FOR SUPPLY AIR TRUNK FOR ACCOMMODATION	1	engine room
	32	FIRE DAMPER FOR RETURN AIR TRUNK FOR ACCOMMODATION	1	engine room
	33	FIRE DAMPER FOR SUPPLY AIR TRUNK FOR ACCOMMODATION	1	engine room
	34	FIRE DAMPER FOR RETURN AIR TRUNK FOR ACCOMMODATION	1	engine room
	35	FIRE DAMPER FOR SUPPLY AIR TRUNK FOR ACCOMMODATION	1	engine room
	36	FIRE DAMPER FOR RETURN AIR TRUNK FOR ACCOMMODATION	1	engine room
	37	FIRE DAMPER FOR SUPPLY AIR TRUNK FOR ACCOMMODATION	1	engine room
	38	FIRE DAMPER FOR RETURN AIR TRUNK FOR ACCOMMODATION	1	engine room
	39	FIRE DAMPER FOR SUPPLY AIR TRUNK FOR ACCOMMODATION	1	engine room
	40	FIRE DAMPER FOR RETURN AIR TRUNK FOR ACCOMMODATION	1	engine room
	41	FIRE DAMPER FOR SUPPLY AIR TRUNK FOR ACCOMMODATION	1	engine room
	42	FIRE DAMPER FOR RETURN AIR TRUNK FOR ACCOMMODATION	1	engine room
	43	FIRE DAMPER FOR SUPPLY AIR TRUNK FOR ACCOMMODATION	1	engine room
	44	FIRE DAMPER FOR RETURN AIR TRUNK FOR ACCOMMODATION	1	engine room
	45	FIRE DAMPER FOR SUPPLY AIR TRUNK FOR ACCOMMODATION	1	engine room
	46	FIRE DAMPER FOR RETURN AIR TRUNK FOR ACCOMMODATION	1	engine room
	47	FIRE DAMPER FOR SUPPLY AIR TRUNK FOR ACCOMMODATION	1	engine room
	48	FIRE DAMPER FOR RETURN AIR TRUNK FOR ACCOMMODATION	1	engine room
	49	FIRE DAMPER FOR SUPPLY AIR TRUNK FOR ACCOMMODATION	1	engine room
	50	FIRE DAMPER FOR RETURN AIR TRUNK FOR ACCOMMODATION	1	engine room
	51	FIRE DAMPER FOR SUPPLY AIR TRUNK FOR ACCOMMODATION	1	engine room
	52	FIRE DAMPER FOR RETURN AIR TRUNK FOR ACCOMMODATION	1	engine room
	53	FIRE DAMPER FOR SUPPLY AIR TRUNK FOR ACCOMMODATION	1	engine room
	54	FIRE DAMPER FOR RETURN AIR TRUNK FOR ACCOMMODATION	1	engine room
	55	FIRE DAMPER FOR SUPPLY AIR TRUNK FOR ACCOMMODATION	1	engine room
	56	FIRE DAMPER FOR RETURN AIR TRUNK FOR ACCOMMODATION	1	engine room
	57	FIRE DAMPER FOR SUPPLY AIR TRUNK FOR ACCOMMODATION	1	engine room
	58	FIRE DAMPER FOR RETURN AIR TRUNK FOR ACCOMMODATION	1	engine room
	59	FIRE DAMPER FOR SUPPLY AIR TRUNK FOR ACCOMMODATION	1	engine room
	60	FIRE DAMPER FOR RETURN AIR TRUNK FOR ACCOMMODATION	1	engine room
	61	FIRE DAMPER FOR SUPPLY AIR TRUNK FOR ACCOMMODATION	1	engine room
	62	FIRE DAMPER FOR RETURN AIR TRUNK FOR ACCOMMODATION	1	engine room
	63	FIRE DAMPER FOR SUPPLY AIR TRUNK FOR ACCOMMODATION	1	engine room
	64	FIRE DAMPER FOR RETURN AIR TRUNK FOR ACCOMMODATION	1	engine room
	65	FIRE DAMPER FOR SUPPLY AIR TRUNK FOR ACCOMMODATION	1	engine room
	66	FIRE DAMPER FOR RETURN AIR TRUNK FOR ACCOMMODATION	1	engine room
	67	FIRE DAMPER FOR SUPPLY AIR TRUNK FOR ACCOMMODATION	1	engine room
	68	FIRE DAMPER FOR RETURN AIR TRUNK FOR ACCOMMODATION	1	engine room
	69	FIRE DAMPER FOR SUPPLY AIR TRUNK FOR ACCOMMODATION	1	engine room
	70	FIRE DAMPER FOR RETURN AIR TRUNK FOR ACCOMMODATION	1	engine room
	71	FIRE DAMPER FOR SUPPLY AIR TRUNK FOR ACCOMMODATION	1	engine room
	72	FIRE DAMPER FOR RETURN AIR TRUNK FOR ACCOMMODATION	1	engine room
	73	FIRE DAMPER FOR SUPPLY AIR TRUNK FOR ACCOMMODATION	1	engine room
	74	FIRE DAMPER FOR RETURN AIR TRUNK FOR ACCOMMODATION	1	engine room
	75	FIRE DAMPER FOR SUPPLY AIR TRUNK FOR ACCOMMODATION	1	engine room
	76	FIRE DAMPER FOR RETURN AIR TRUNK FOR ACCOMMODATION	1	engine room
	77	FIRE DAMPER FOR SUPPLY AIR TRUNK FOR ACCOMMODATION	1	engine room
	78	FIRE DAMPER FOR RETURN AIR TRUNK FOR ACCOMMODATION	1	engine room
	79	FIRE DAMPER FOR SUPPLY AIR TRUNK FOR ACCOMMODATION	1	engine room
	80	FIRE DAMPER FOR RETURN AIR TRUNK FOR ACCOMMODATION	1	engine room
	81	FIRE DAMPER FOR SUPPLY AIR TRUNK FOR ACCOMMODATION	1	engine room
	82	FIRE DAMPER FOR RETURN AIR TRUNK FOR ACCOMMODATION	1	engine room
	83	FIRE DAMPER FOR SUPPLY AIR TRUNK FOR ACCOMMODATION	1	engine room
	84	FIRE DAMPER FOR RETURN AIR TRUNK FOR ACCOMMODATION	1	engine room
	85	FIRE DAMPER FOR SUPPLY AIR TRUNK FOR ACCOMMODATION	1	engine room
	86	FIRE DAMPER FOR RETURN AIR TRUNK FOR ACCOMMODATION	1	engine room
	87	FIRE DAMPER FOR SUPPLY AIR TRUNK FOR ACCOMMODATION	1	engine room
	88	FIRE DAMPER FOR RETURN AIR TRUNK FOR ACCOMMODATION	1	engine room
	89	FIRE DAMPER FOR SUPPLY AIR TRUNK FOR ACCOMMODATION	1	engine room
	90	FIRE DAMPER FOR RETURN AIR TRUNK FOR ACCOMMODATION	1	engine room
	91	FIRE DAMPER FOR SUPPLY AIR TRUNK FOR ACCOMMODATION	1	engine room
	92	FIRE DAMPER FOR RETURN AIR TRUNK FOR ACCOMMODATION	1	engine room
	93	FIRE DAMPER FOR SUPPLY AIR TRUNK FOR ACCOMMODATION	1	engine room
	94	FIRE DAMPER FOR RETURN AIR TRUNK FOR ACCOMMODATION	1	engine room
	95	FIRE DAMPER FOR SUPPLY AIR TRUNK FOR ACCOMMODATION	1	engine room
	96	FIRE DAMPER FOR RETURN AIR TRUNK FOR ACCOMMODATION	1	engine room
	97	FIRE DAMPER FOR SUPPLY AIR TRUNK FOR ACCOMMODATION	1	engine room
	98	FIRE DAMPER FOR RETURN AIR TRUNK FOR ACCOMMODATION	1	engine room
	99	FIRE DAMPER FOR SUPPLY AIR TRUNK FOR ACCOMMODATION	1	engine room
	100	FIRE DAMPER FOR RETURN AIR TRUNK FOR ACCOMMODATION	1	engine room

LIST OF FIRE CONTROL & SAFETY PLAN

| SYMBOL | DESCRIPTION | CSR | TWD | TWT | UWD | UWT | MSR | PCP | 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 | 10 | 11 | 12 | 13 | 14 | 15 | 16 | 17 | 18 | 19 | 20 |

Illustration 8.1a Engine Room Fire Main System



Illustration 8.2a Fire and Wash Deck System (Deck Fire Main System)



Key

- Fire Main Line
- HB Hose Box
- HR Hose Reel

Illustration 8.2b Fire and Wash Deck System (Accommodation Fire Main System)



Illustration 8.3a Water Spray System



Illustration 8.4a Deck Dry Powder System





Illustration 8.4b Dry Powder Fire Extinguishing System



Illustration 8.5a CO_2 Fire Extinguishing System





Key

- CO2 Fire Exiting Line
- Drain Line

Illustration 8.6a Quick Closing Valves and Fire Dampers System



Illustration 8.7a Engine Room Local Fire Fighting System



Illustration 8.8a High Expansion Foam System